


fault	Check	Test	Rectification
battery not being charged CAUTION: The vehicle battery must never be disconnected while the engine is running Warning light stays on Warning light does not function when ignition switched on	1, 2, 3, 4, 5	5. Alternator output Connect a voltmeter across the battery terminals. Connect an ammeter into the alternator battery sensing circuit either at the battery terminal or solenoid. Switch on all loads (except wipers) for one minute. Run the engine at 3,000 rev/min and wait until the ammeter reading is stable. (i) Ammeter reading Zero — Faulty alternator (ii) Voltmeter reading below 13.6V and battery in low state of charge (iii) Ammeter reading below 10A, voltmeter reading below 13.6V (iv) Ammeter reading above 10A, voltmeter reading above 14.6V	Overhaul alternator
	1, 2, 3, 4, 6, 7	6. Drive belt: Check the drive belt is not broken or slipping	Bench test and overhaul
	1, 2, 3, 4, 8, 5	7. IND lead: Disconnect the IND lead from the alternator, start engine and run above idle speed. (i) Warning light stays on — Short circuit to earth between IND lead and warning light (ii) Warning light goes out	Renew voltage regulator
		8. Warning light bulb: Check warning lamp bulb (i) Bulb faulty (ii) Bulb not faulty	Renew voltage regulator
TEST EQUIPMENT Voltmeter 0 - 20 V moving coil Ammeter 5-0-50A moving coil Hydrometer		9. Alternator plug connections: Remove plug from alternator, switch on ignition and connect a voltmeter between earth and each terminal in turn. (i) Voltmeter reads 12V (ii) Voltmeter does not read 12V — cable circuits faulty	Adjust or renew
IGNITION SYSTEM Engine will not fire		10. Engine cranking speed: Too low 11. Sparking plugs: Check for dirty electrodes or incorrect gaps for faulty operation on pressure test equipment 12. Contact breaker points: Check for incorrect gap, burning or pitting 13. Distributor cap: Check for 'tracking' (thin lines of burned bakelite), ensure cap is clean and dry and that the centre brush moves freely with no excessive side movement and contacts the rotor arm.	Repair or renew
	10, 11, 12, 13, 14, 1		Carry out Test 5
			Renew
			Carry out Test 9
			Carry out Test 5
			Check cable continuity; repair or renew
			See STARTING SYSTEM
			Clean, set gaps or renew contact breaker distributors carry out Test 12
			Clean, adjust or renew
			Rectify or replace. Carry out Test 14. Rectify or replace. Carry out Test 14.

continued

fault	Check	Test	Rectification
IGNITION SYSTEM		a. Connect 0 - 1 V voltmeter as in Test 15c, fit a jumper lead from earth to distributor body, with ignition on and contact breaker points closed: (i) Below 0.2V (ii) Above 0.2V — High resistance or open circuit in distributor	Remake earth connections between distributor body and earth Check/repair or renew contact breaker points, base plate screws earth lead or supply lead as necessary Carry out Test 15g
		b. Connect 0 - 20 V voltmeter as in Test 15b, with ignition on and contact breaker points open: (i) Above 12 V — Continuity in primary windings of coil, supply line and ballast resistor if fitted (ii) Zero — open circuit feed to coil, open circuit primary windings, open circuit ballast resistor if fitted or short circuit in distributor or coil negative lead (iii) ballast resistor if fitted or short circuit in distributor or coil negative lead Connect 0 - 20 V voltage as in Test 15b, with ignition on and contact breaker points open. Remove coil negative lead from coil and recheck voltage: (i) Above 12V — Shortcircuit in coil, negative lead or distributor (ii) Zero — reconnect coil negative lead Connect 0 - 20 V voltmeter between earth and coil positive terminal, with ignition on and contact breaker points closed: (i) Above 12V — Coil primary windings open circuit (ii) 11.5V - 12V without ballast resistor If result of Test 15f was above 12V 5V - 7V with ballast resistor L. T. circuit is satisfactory (iii) Below 11.5V or zero without ballast resistor — Excessive resistance or open circuit supply to coil. Leaving the voltmeter connected to earth, work back through the supply circuit at the terminals on the ignition switch and solenoid until the resistance or open circuit is located (iv) Below 5V or zero with ballast resistor — Excessive resistance or open circuit in supply to coil Connect 0 - 20 V voltmeter between earth and the lead from the ballast resistor to the coil positive terminal, with the ignition on and contact breaker points closed: (i) 5V - 7V or above 12V — Fault in the ballast resistor to coil lead (ii) Below 5V or zero — Excessive resistance or open circuit between battery and coil Connect 0 - 20 V voltmeter between earth feed lead to ballast resistor, with ignition on and contact breaker points closed: (i) Above 12V — Fault in ballast resistor (ii) Zero or below 11.5V — Fault in supply circuit from battery. Leaving the voltmeter connected to earth, work back through the supply circuit at the terminals on the ignition switch and solenoid until the fault is located.	Check contact breaker points correctly fitted, short circuit in condenser (or capacitor when ballast resistor fitted) or supply lead; repair or renew Carry out Test 15g Carry out Test 15f Check contact breaker points correctly fitted, short circuit in condenser (or capacitor when ballast resistor fitted) or supply lead; repair or renew Carry out Test 15g Renew coil Fault elsewhere Rectify and recheck Carry out Test 15H Repair or renew lead then re-test Carry out Test 15j Renew and re-test. If satisfactory fault elsewhere Rectify and re-test. If satisfactory fault elsewhere

continued

Fault	Check	Test	Rectification
IGNITION SYSTEM	14. H.T. Circuit	 <p>a. Disconnect main H.T. lead from distributor cap, hold approximately 6 mm (¼ in) from a good earth, ensure contact breaker points are closed, switch on ignition and flick contact breaker points open.</p> <p>(i) Good healthy spark — Main H.T. lead, condenser and coil satisfactory</p> <p>(ii) Poor or no spark</p> <p>b. Replace main H.T. lead with a known good H.T. lead and repeat Test</p> <p>(i) Good healthy spark — Original H.T. lead faulty</p> <p>(ii) Poor or no spark</p> <p>c. Replace condenser with a known good one and repeat Test</p> <p>(i) Good healthy spark — Original condenser faulty</p> <p>(ii) Poor or no spark</p> <p>d. Replace ignition coil with a known good coil and repeat Test</p> <p>(i) Good healthy spark — original coil faulty</p>	<p>Carry out Test 14e</p> <p>Carry out Test 14b</p> <p>Renew main H.T. lead. Carry out Test 14e</p> <p>Carry out Test 14c</p> <p>Renew condenser. Carry out Test 14e</p> <p>Carry out Test 14d</p> <p>Renew coil, refit original H.T. lead and condenser and repeat Tests 14a and b, or carry out Test 14e</p>
TEST EQUIPMENT	15. L.T. circuit continuity check:	<p>e. Hold loose end of main H.T. lead approximately 3 mm (¼ in) from the rotor arm electrode. Ensure contact breaker points are closed, switch on ignition and flick points open</p> <p>(i) Good healthy spark — Rotor arm shorting to earth</p> <p>(ii) Very faint or no spark — Rotor arm insulation satisfactory</p> <p>a. Check battery voltage and state of charge</p> <p>b. Connect voltmeter 0 - 1V between earth and coil negative terminal with ignition on and contact breaker points closed:</p> <p>(i) Below 0.2V</p> <p>(ii) Above 0.2V — Resistance or open circuit</p> <p>c. Connect 0 - 1V voltmeter between earth and distributor L.T. terminal with ignition on and contact breaker points closed:</p> <p>(i) Below 0.2V — Resistance or open circuit between coil negative and distributor L.T. terminal</p> <p>(ii) Above 0.2V — Resistance or open circuit between earth and distributor L.T. terminal</p>	<p>Renew rotor arm</p> <p>Carry out Test 15</p> <p>See STARTING SYSTEM</p> <p>Carry out Test 15e</p> <p>Carry out Test 15c</p> <p>Renew lead</p> <p>Carry out Test 15d</p>

continued

Fault	Test	Rectification
IGNITION SYSTEM (continued)	<p>1. Connect voltmeter (B) as in Test 15C, fit a jumper lead from earth to distributor body, with ignition on and contact breaker points closed:</p> <p>(i) Below 0.2V</p> <p>(ii) Above 0.2V — High resistance or open circuit in distributor</p> <p>2. Connect voltmeter (A) as in Test 15b, with ignition on and contact breaker points open:</p> <p>(i) Above 12V — Continuity in primary windings of coil, supply line and ballast resistor if fitted</p> <p>(ii) Zero — open circuit feed to coil, open circuit primary windings, open circuit ballast resistor if fitted or short circuit in distributor or coil — ve lead</p> <p>3. Connect voltage (A) as in Test 15b, with ignition on and contact breaker points open. Remove coil — ve lead from coil and recheck voltage:</p> <p>(i) Above 12V — Short circuit in coil, —ve lead or distributor</p> <p>(ii) Zero — reconnect coil — ve lead</p> <p>4. Connect voltmeter (A) between earth and coil +ve terminal, with ignition on and contact breaker points closed:</p> <p>(i) Above 12V — Coil primary windings open circuit</p> <p>(ii) 11.5V - 12V without ballast resistor } If result of Test 15f was above 12V 5V - 7V with ballast resistor } L.T. circuit is satisfactory</p> <p>(iii) Below 11.5V or zero without ballast resistor — Excessive resistance or open circuit supply to coil. Leaving the voltmeter connected to earth, work back through the supply circuit at the terminals on the ignition switch and solenoid until the resistance or open circuit is located</p> <p>(iv) Below 5V or zero with ballast resistor — Excessive resistance or open circuit in supply to coil</p> <p>5. Connect voltmeter (A) between earth and the lead from the ballast resistor to the coil +ve terminal, with the ignition on and contact breaker points closed:</p> <p>(i) 5V - 7V or above 12V — Fault in the ballast resistor to coil lead</p> <p>(ii) Below 5V or zero — Excessive resistance or open circuit between battery and coil</p> <p>6. Connect voltmeter (A) between earth feed lead to ballast resistor, with ignition on and contact breaker points closed:</p> <p>(i) Above 12V — Fault in ballast resistor</p> <p>(ii) Zero or below 11.5V — Fault in supply circuit from battery. Leaving the voltmeter connected to earth, work back through the supply circuit at the terminals on the ignition switch and solenoid until the fault is located.</p>	<p>Rectification</p> <p>Remake earth connections between distributor body and earth</p> <p>Check/repair or renew contact breaker points, base plate screws earth lead or supply lead as necessary</p> <p>Carry out Test 15g</p> <p>Carry out Test 15f</p> <p>Check contact breaker points correctly fitted, short circuit in condenser (or capacitor when ballast resistor fitted) or supply lead; repair or renew</p> <p>Carry out Test 15g</p> <p>Renew coil</p> <p>Fault elsewhere</p> <p>Rectify and recheck</p> <p>Carry out Test 15h</p> <p>Repair or renew lead then re-test</p> <p>Carry out Test 15j</p> <p>Renew and re-test. If satisfactory fault elsewhere</p> <p>Rectify and re-test. If satisfactory fault elsewhere</p>

continued