

VOYAGER OFFROAD, LLC

Roof rack installation instructions

Hardware:

- 6- Rail Mounting Blocks
- 2- Front Mounting Blocks
- 8- 6mm-1.00 55mm Bolts
- 8- 6mm flat washer
- 6- Stainless Steel 5/16 Washers

You will need:

- 1- Flat screwdriver
- 1- Torx Bit and driver
- 1- 10 mm socket and driver
- 1- 1/2" drill bit

Installation Instructions:

Remove all packaging and inspect that all hardware was included.

Lower vehicle to access mode.

For 2006 and newer, remove black plastic cover from the front of your vehicle on either side of the front sunroof. (For 2005, you will need to drill a hole in each plastic weather strip to reveal the mounting point located underneath or contact your local retailer to purchase the newer version of these covers.)

Use screwdriver to remove 3 black plastic bolt covers located in each rail.

Using your torx remove the 3 bolts. The bolts will stay on the rail.

Remove rails to remove bolts. Place the 6 provided 5/16 washers on the 6 mounting points on your vehicle.

Drill out the BOTTOM hole only of the rails to 1/2". 6 in all.

Reposition the rails on your vehicle.

Place mounting blocks into rail over mounting holes in rail. Repeat on opposite side.

With the assistance of another person pick up the roof rack.

It is best to walk from the rear of the vehicle toward the front.

Gently lower one side onto mounting blocks then the other.

Adjust the roof rack forward or back as needed.

Insert bolt with washer through the roof rack, block, rail, washer and into vehicle.

Repeat on opposite side.

Using your tightening device and 10 mm, tighten the bolts. Work your way from front to back, alternating sides.

Discard all packaging and enjoy your new Voyager Offroad, LLC. Voyager Roof Rack

If you have any questions regarding care or maintenance about your new product, please call 941 235-*RACK* or email info@roverracks.com

VOYAGER OFFROAD

Discovery 3 LR3 Voyager Roof Rack



Installation Instructions
for Voyager Roof Racks

Discovery 3/ LR3
2005-2010

Hardware:

- 6- Rail Mounting Blocks
- 2- Front Mounting Blocks
- 8- 6mm-1.00 55mm Bolts
- 8- 6mm flat washer
- 6- Stainless Steel 5/16 Washers

You will need:

- 1- Flat screwdriver
- 1- Torx Bit and driver
- 1- 10 mm socket and driver
- 1- 1/2" drill bit

Installation Instructions:

Remove all packaging and inspect that all hardware was included.

Lower vehicle to access mode.

For 2006 and newer, remove black plastic cover from the front of your vehicle on either side of the front sunroof. (For 2005, you will need to drill a hole in each plastic weather strip to reveal the mounting point located underneath or contact your local retailer to purchase the newer version of these covers.)

Use screwdriver to remove 3 black plastic bolt covers located in each rail.

Using your torx remove the 3 bolts. The bolts will stay on the rail.

Remove rails to remove bolts. Place the 6 provided washers on the 6 mounting points on your vehicle.

Drill out the BOTTOM hole only of the rails to 1/2". 6 in all.

Reposition the rails on your vehicle.

Place mounting blocks into rail over mounting holes in rail. Repeat on opposite side.

With the assistance of another person pick up the roof rack.

It is best to walk from the rear of the vehicle toward the front.

Gently lower one side onto mounting blocks then the other.

Adjust the roof rack forward or back as needed.

Insert bolt with washer through the roof rack, block, rail, washer and into vehicle.

Repeat on opposite side.

Using your tightening device and 10 mm, tighten the bolts. Work your way from front to back, alternating sides.

Discard all packaging and enjoy your new Voyager Offroad, LLC. Voyager Roof Rack

If you have any questions regarding care or maintenance about your new product, please call 941 235-*RACK* or email info@roverracks.com

VOYAGER OFFROAD

Discovery 3 LR3 Voyager Roof Rack



Installation Instructions
for Voyager Roof Racks

Discovery 3/ LR3
2005-2010