




217. in rear of LH front door
 M114 Left Front Door Lock Actuator
 C507 (4-W) (Without Theft Alarm)
 C507 (6-W) (With Theft Alarm)



218. in rear of LH front door
 X201 Left Front Door Key Switch
 C504 (4-W)



219. in front of LH front door (RH similar)
 M130 Left Front Window Motor
 M133 Right Front Window Motor
 C500 (2-B) (Left)
 C600 (2-B) (Right)



220. in top rear of RH front door
 M122 Right Front Door Lock Actuator
 C607 (2-W) (Without Theft Alarm)
 C607 (6-W) (With Theft Alarm)