


Refit



NOTE: If a new distributor is being fitted, mark body in same relative position as distributor removed.




10M0427

8. Leads for distributor cap should be connected as illustrated.

Figures 1 to 8 inclusive indicate plug lead numbers.

RH-Right hand side of engine, when viewed from rear.

LH-Left hand side of engine, when viewed from rear.



RR616M