





- X121  
Right Front Seat Control Switch
- [1] Forward
  - [2] Backward
  - [3] Front Down
  - [4] Front Up
  - [5] Recline
  - [6] Raise
  - [7] Rear Down
  - [8] Rear Up



