



Description: Engine control module (ECM)
 Location: Behind RH side of fascia



Colour:
 Gender:

Cav	Col	Cct
1	YW	ALL
2	YG	ALL
3	NR	ALL
4	BU	18
6	RB	34
7	R	ALL
9	RB	ALL
10	R	ALL
14	YR	ALL
15	YS	ALL
16	BO	18
17	B	ALL
18	RK	ALL
20	SU	ALL
21	RB	ALL
22	G	ALL
23	UG	ALL
24	YLG	ALL
25	RB	ALL
27	YB	ALL
28	YK	ALL
29	SP	ALL
30	BY	18
30	SY	34
31	GW	ALL
32	BY	ALL
34	SLG	ALL
35	W	ALL
36	KB	ALL
40	YN	ALL
41	YU	ALL
42	US	ALL
43	RG	ALL
44	GU	ALL
45	SCR	ALL
46	KB	ALL
48	B	ALL