


## PASSENGER COMPARTMENT FUSE BOX



M86 4473A

### Relays (R)

1. LH indicators
2. RH indicators
3. Rear window lift
4. Ignition coils - V8 only
5. Daylight running lamps - if fitted
6. Daylight running lamps - if fitted