




101. lower LH rear of engine compartment (MFI-V8)  
 X139 Left Heated Oxygen Sensor  
 C112 (3-W)



102. lower LH rear of engine compartment (SFI-V8)  
 X139 Left Heated Oxygen Sensor



103. lower LH rear of engine (SFI-V8)  
 X250 Crankshaft Position Sensor  
 C1004 (2-B)



104. lower LH side of engine (SFI-V8)  
 X295 Left Knock Sensor  
 C1022 (2-B)