
Amplifier - power

∞ 86.50.36


Remove

1. Slide LH front seat fully rearwards.



M86 6002

- 2. Remove 2 bolts securing power amplifier cradle to bracket.
- 3. Withdraw power amplifier and cradle assembly, disconnect multiplug from power amplifier and remove assembly.



4. Remove 3 bolts securing power amplifier to cradle and remove power amplifier.

Refit

- 1. Locate power amplifier to cradle and fit and tighten bolts.
- 2. Connect multiplug and locate power amplifier and cradle assembly to bracket.
- 3. Fit and tighten bolts securing cradle to bracket.
- 4. Position seat to mid position.