

# Warning lights

---



## Headlight main beam - BLUE

Illuminates when the headlights are switched to main beam.



## Direction indicators - GREEN

The left or right warning light flashes in time with the

corresponding left or right direction indicator lights whenever they are operated. If the warning light fails to flash, or flashes very rapidly, this may indicate a bulb failure in one of the direction indicator lights.

If the hazard switch is pressed, both warning lights will flash in conjunction with the direction indicator lights.



## Trailer direction indicators - GREEN

The light illuminates briefly as a bulb check when the starter switch is turned to position II. If a trailer is attached, the light illuminates in conjunction with the vehicle direction indicator lights to show that all trailer indicator lights are functioning correctly. In the event of a direction indicator bulb failure on the trailer, the warning light remains off.



## Differential lock - RED

Illuminates whenever the differential is locked.

While carrying out maintenance operations on your vehicle, it may be necessary for the dealer to lock the differential between the front and rear axles. This will cause the warning light to illuminate.

The dealer should always unlock the differential before returning the vehicle to the owner. However, if the light illuminates when the starter switch is turned on, this indicates that this has not been done. The vehicle should not be driven in this condition because ABS performance will be impaired and Traction Control will be disabled. Contact your dealer immediately and ask for the differential to be unlocked.



## Battery charging - RED

The light illuminates as a bulb check when the starter switch is turned to position 'II' and extinguishes once the engine is running. If it remains on, or illuminates whilst driving, a fault is indicated. Seek qualified assistance urgently.



## Seat belt - RED

The light illuminates when the starter switch is turned to position 'II' and extinguishes after approximately 6 seconds. Illumination of the light will also be accompanied by a 6 second warning chime.