



Item	Part Number	Description
1	-	Coolant outlet elbow
2	-	Bolt
3	-	Thermostat housing
4	-	Bolt

The composite thermostat housing is installed between the two cylinder banks, immediately above the coolant pump. The thermostat controls the flow of coolant through the radiator.

## CRANKSHAFT AND SUMP COMPONENTS