

PUBLISHED: 23-JUN-2017  
2017.0 DISCOVERY (LR), 501-05

INTERIOR TRIM AND ORNAMENTATION

# TAILGATE TRIM PANEL (G2008370)

## REMOVAL AND INSTALLATION

76.49.23	CARPET - TAILGATE - RENEW	ALL DERIVATIVES	0.2	USED WITHINS	
----------	---------------------------------	--------------------	-----	-----------------	--

### PART(S)

STEP	PART NAME	QUANTITY
Removal Step 3	Retaining clips	14

## REMOVAL

### ⚠ CAUTION:

Make sure to protect the paintwork.

### ⚠ NOTE:

Removal steps in this procedure may contain installation details.


1.



Remove the trim panel.

---

2.

 NOTE:

Do not remove the component at this stage.



Release the tailgate trim panel.

*Torque: 1.3 Nm*


3.

⚠ CAUTION:

Make sure the wiring harness and electrical connectors are not damaged during the tailgate trim panel removal.

△ NOTE:


Do not disassemble further if the component is removed for access only.



Remove the tailgate trim panel.

Renew Part: *Retaining clips* Quantity: 14 .


4.



E195762

Remove the switch.

5.



E195761

Remove the interior rear lamps.

## INSTALLATION

1. To install, reverse the removal procedure.