Mr./Mrs./Ms.:	Model:	Reg. No.:
Invoice/Job No.:	Odometer Reading:	V.I.N.:

В

72

Α

В

96

Α

108

В

120



DISCOVERY (ALL MODELS UK & EU FROM 14MY)

Months ,000 miles: 12 **16** 24 **32** 36 **48** 48 84 **112** 64 80 96 128 144 160 Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked * Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and materi

В

Α

60

Service type:

Α

В

Α

Onoon	711101		ooking procedure, clearing, adjusting, repairing or replacing to cabject to okta labour and ma
	Α	В	MAIN SERVICE (VEHICLE INTERIOR)
1. 2. 3.			Check condition and security of seats and seatbelts Check operation of all lamps, horns and warning indicators Check operation of front/rear wipers and washers and condition of wiper blades
4. 5.			Select the LOW range gears and drive the vehicle 3 to 4 vehicle lengths then re-select HIGH range gears Replace pollen filter
			MAIN SERVICE (VEHICLE EXTERIOR)
6. 7. 8. 9. 10. 11. 12.			Check tyre pressures, condition and tread depth. Remove road wheels Inspect brake pads for wear, calipers for leaks and disks for condition Replace brake fluid (<i>Every 3 years</i>)* Renew fuel filter element (<i>Diesel</i>) Drain fuel sedimentor (<i>Diesel</i>) Refit road wheels to opposite sides of the same axle (Use anti-sieze compound on spigot bore) Not vehicles fitted with uni-directional tyres Check operation of door checks, bonnet catch & fuel flap and lubricate door checks Apply lubricant to door seals - Nordic markets only
15.			Check condition of removable towbar
16. 17. 18. 19. 20. 21. 22. 23. 24. 25. 26. 27.	112k 112k 112k	64k	MAIN SERVICE (UNDER BONNET) Check anti-freeze specific gravity Renew coolant (Every 10 years) Renew spark plugs Renew air cleaner element (Petrol) Renew air cleaner element (Diesel) Check condition of ancillary driving belts Renew supercharger driving belt (Every 7 years) Renew ancillary driving belts (Every 10 years) Renew front and rear camshaft timing belts, tensioners and tensioner bolt (Diesel Every 7 years) Check/top-up brake and PAS fluid levels and screen washer reservoirs Check/top-up battery electrolyte level - low maintenance battery fitted Renew engine oil and filter MAIN SERVICE (UNDER VEHICLE)
28.			
29. 30. 31. 32. 33. 34. 35.	80k 80k	160k 160k	Renew locking differential oil (Every 5 years) Renew locking differential oil (Every 5 years) Renew front and rear non-locking differential oil (Every 10 years) Renew automatic gearbox fluid and filter (Every 10 years) Renew fuel tank filter (Petrol) (Every 10 years) Check for free play in all suspension and body mounting rubbers Check condition of all suspension, driveshafts and steering boots and gaiters Replace all flexible brake hoses (Every 6 years)* Check visually brake servo hose, brake, fuel and PAS pipes, unions, and electrical harnesses for chafing, leaks and corrosion

ial cost.		MAINTENANCE CHECK SHEET
A 37.	B	MAIN SERVICE (UNDER VEHICLE) Adjust the electric park brake shoes Check for fluid leaks Check exhaust system for leaks, security and damage Check steering rod ball joint fixings and condition of ball joints and dust covers If fault lamp(s) are illuminated, interrogate that system using IDS/SDD and report findings* Carry out road test (see WARNING over page) Reset service interval announcement indicator Reset oil level indicator (if fitted) Endorse service record Check for any applicable outstanding service actions or recalls Report any unusual features of vehicle condition and additional work required
road and cli stop/start op of trailers.	matic perati	items listed, are those recommended for vehicles operating under normal driving, conditions. More frequent attention may be necessary if the vehicle is subject to on, extremes of temperature, dusty conditions, off road driving or frequent towing apleted, cosmetic/corrosion inspection check completed and service portfolio book

JLR 19 17 10_1E 7/8/2013

WARNING: Two wheel roller tests must not be carried out. Four wheel roller tests must be limited to 5 km/hour (3 miles/hour).

IMPORTANT - OIL CHANGE 3.0L DIESEL ENGINES

If the vehicle is operated on fuel with a high sulphur content (over 0.7) the oil change intervals must not exceed 6,500Km (4000 miles)

If the vehicle is operated on fuel with a moderate sulphur content (between 0.3 - 0.7) the oil change intervals must not exceed 13,000Km (8000 miles)

IT IS RECOMMENDED THAT:

Comments/Remedial Work

After 50 miles continuous use in severe off road conditions - wading, deep mud and abrasive grit/slurry - the electric park brake should be inspected, cleaned and adjusted, and the ancillary drive belt should be inspected and cleaned.

Air suspension vehicles used extensively in arduous/ off road conditions will require the compressor inlet filter to be replaced at more regular intervals.

When the vehicle is used in dusty or field conditions or deep wading, frequent attention to the air cleaner may be required.

When the vehicle is used in areas where fuel quality is poor, more frequent draining of the fuel filter/ sedimentor may be required.

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

GLOSSARY:

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 16,000 mile intervals, whichever occurs first.

Main Service "A" is applicable at 12 months/16,000 miles, 36 months/48,000 miles, 60 months/80,000 miles 84 months/112,000 miles and so on.

Main Service "B" is applicable at 24 months/32,000 miles, 48 months/64,000 miles, 72 months/96,000 miles, 96 months/128,000 miles and so on.

NOTE: The service required should be at the time or distance stated, which ever occurs first.

	·	
_		
	_	