



# MAINTENANCE SCHEDULE

2008 LR2

Owner's Name: \_\_\_\_\_

Date: \_\_\_\_\_ Mileage \_\_\_\_\_ RO#: \_\_\_\_\_

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	6	12	18	24	30	36	42	48
	⊖ MILES (Thousands)	7.5	15	22.5	30	37.5	45	52.5	60
	⊙ KM (Thousands)	12	24	36	48	60	72	84	96
⊙ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
<b>1. VEHICLE INTERIOR</b>									
Reset the Service Interval Indicator		<input type="checkbox"/>							
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check parking brake operation			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
<b>2. VEHICLE EXTERIOR</b>									
Anti-corrosion check. Use <b>Corrosion Perforation Form</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks, hood latch and fuel flap. Lube door checks.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
<b>3. ENGINE COMPARTMENT</b>									
Check battery condition and top-up electrolyte if required.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect serpentine drive belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace serpentine drive belts (105k miles)									
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years) *							<input type="checkbox"/>		
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years)									
Replace spark plugs (75k miles)									
Replace air-cleaner element					<input type="checkbox"/>				<input type="checkbox"/>
<b>4. UNDER VEHICLE</b>									
Change engine oil and replace filter		<input type="checkbox"/>							
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disk condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures are set to recommended levels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tires for damage and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – <b>except uni-directional tires which install on same side</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect steering ball joints for wear, damaged dust covers			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check for suspension mounting rubber freeplay			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace flexible brake hoses (6 years) *									
Change automatic transmission fluid and filter (10 years or 150k miles)									
Change transfer unit oil (10 years or 150k miles)									
Change rear differential oil (10 years or 150k miles)									
<b>5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED *</b>									
If fault lamps are lit use IDS to find the faults and report *	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No
<b>6. ROAD TEST</b>									
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>							

\* Labor cost not included in scheduled time.

### NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



# MAINTENANCE SCHEDULE

2008 LR2

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	54	60	66	72	78	84	90	96
	⊙ MILES (Thousands)	67.5	75	82.5	90	97.5	105	112.5	120
	⊙ KM (Thousands)	108	120	132	144	156	168	180	192
⊙ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
<b>1. VEHICLE INTERIOR</b>									
Reset the Service Interval Indicator		<input type="checkbox"/>							
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check parking brake operation			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
<b>2. VEHICLE EXTERIOR</b>									
Anti-corrosion check. Use <b>Corrosion Perforation Form</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks, hood latch and fuel flap. Lube door checks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
<b>3. ENGINE COMPARTMENT</b>									
Check battery condition and top-up electrolyte if required.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect serpentine drive belts			<input type="checkbox"/>		<input type="checkbox"/>				<input type="checkbox"/>
Replace serpentine drive belts (105k miles)							<input type="checkbox"/>		
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years) *					<input type="checkbox"/>				
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years)									
Replace spark plugs (75k miles)			<input type="checkbox"/>						
Replace air-cleaner element					<input type="checkbox"/>				<input type="checkbox"/>
<b>4. UNDER VEHICLE</b>									
Change engine oil and replace filter		<input type="checkbox"/>							
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disk condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures are set to recommended levels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tires for damage and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – <b>except uni-directional tires which install on same side</b>			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect steering ball joints for wear, damaged dust covers			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check for suspension mounting rubber freeplay			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace flexible brake hoses (6 years)*					<input type="checkbox"/>				
Change automatic transmission fluid and filter (10 years or 150k miles)									
Change transfer unit oil (10 years or 150k miles)									
Change rear differential oil (10 years or 150k miles)									
<b>5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED *</b>	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No
If fault lamps are lit use IDS to find the faults and report*		<input type="checkbox"/>							
<b>6. ROAD TEST</b>									
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>							

\* Labor cost not included in scheduled time.

### NOTIFICATION OF SERVICE REQUIREMENTS:

- ♦ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ♦ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ♦ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.

