



MAINTENANCE SCHEDULE

2006 -2009 LR3

Owner's Name: _____

Date: _____ Mileage: _____ RO#: _____

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	6	12	18	24	30	36	42	48
	⊙ MILES (Thousands)	7.5	15	22.5	30	37.5	45	52.5	60
	⊙ KM (Thousands)	12	24	36	48	60	72	84	96
⊙ See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front / rear wiper washer systems; check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks; lube door checks, hood latch and fuel flap			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Inspect serpentine drive belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)							<input type="checkbox"/>		
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace air-cleaner element									<input type="checkbox"/>
4. UNDER VEHICLE									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures are set to recommended levels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tires for damage and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric parking brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.					<input type="checkbox"/>				<input type="checkbox"/>
Check torque of tie rod ends; tighten to 76 Nm (56 lbf ft)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions					<input type="checkbox"/>				<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
5. REMEDIAL WORK / SERVICE CAMPAIGN NEEDED*									
If fault lamps are illuminated, use IDS to find the faults and report	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No
6. ROAD TEST									
Select LOW range, move vehicle 60 ft (18m), select HIGH range			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time.

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



MAINTENANCE SCHEDULE

2006 -2009 LR3

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	54	60	66	72	78	84	90	96
	⊖ MILES (Thousands)	67.5	75	82.5	90	97.5	105	112.5	120
	⊖ KM (Thousands)	108	120	132	144	156	168	180	192
⊖ See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front / rear wiper washer systems; check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks; lube door checks, hood latch & fuel flap			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Inspect serpentine drive belts			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace serpentine drive belts (V6 at 105k miles)							<input type="checkbox"/>		
Replace serpentine drive belts (V8 at 150k miles)	At 150,00 miles / 240,000 Kilometers								
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)					<input type="checkbox"/>				
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years)									<input type="checkbox"/>
Replace spark plugs (at 90k miles)					<input type="checkbox"/>				
Replace spark plugs (V8 at 105k miles)							<input type="checkbox"/>		
Replace air-cleaner element									<input type="checkbox"/>
4. UNDER VEHICLE									
Change engine oil and replace filter	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Inspect for brake pad wear, caliper leaks and disc condition		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Check tire pressures are set to recommended levels		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Check tires for damage and tread depth		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Check adjustment of electric parking brake		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Lubricate wheel centers.		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Inspect for under vehicle fluid leaks		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Check exhaust system for leaks and damage		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Inspect steering ball joints for wear, damaged dust covers				<input type="checkbox"/>					<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.				<input type="checkbox"/>					<input type="checkbox"/>
Check torque of tie rod ends; tighten to 76 Nm (56 lbf ft)		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Inspect brake, fuel lines, PAS hoses and unions				<input type="checkbox"/>					<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage				<input type="checkbox"/>					<input type="checkbox"/>
Replace flexible brake hoses (6 years)*				<input type="checkbox"/>					
Change automatic transmission fluid and filter (10 years)									<input type="checkbox"/>
Change transfer gearbox oil (at 75k and 150k miles)		<input type="checkbox"/>							
Change front and rear axle oil (10 years)									<input type="checkbox"/>
Change locking differential oil (at 75k and 150k miles)		<input type="checkbox"/>							
5. REMEDIAL WORK / SERVICE CAMPAIGN NEEDED*									
If fault lamps are illuminated, use IDS to find the faults and report	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. ROAD TEST									
Select LOW range, move vehicle 60 ft (18m), select HIGH range		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Road test vehicle		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>	
Record performance of Service in Passport to Service	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time.

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.

